Password

To change the password of the currently logged in user, enter the old password, enter the new password twice and then click **Apply** to save the changes.



From:
http://wiki.myakitio.com/ - **MyAkitio Wiki**

Permanent link:
http://wiki.myakitio.com/applications_password

Last update: **2012/12/20 14:03**