


# Server Info

All the important information about your network drive is displayed here. If you contact tech support, please refresh the data and include this information in your ticket or e-mail.



| Field                       | Description  |
|-----------------------------|--|
| <b>Registration Name</b>    | The device name used for login via web portal.   |
| <b>Host Name</b>            | The host name of your network drive.   |
| <b>Workgroup Name</b>       | The name of the Workgroup the network drive belongs to (used for the Samba server).        |
| <b>Local IP Address</b>     | The local IP address (LAN) of your network drive.  |
| <b>UPnP Port Forwarding</b> | The external IP address (WAN) and port number used for remote login to your network drive. |
| <b>MAC Address</b>          | The MAC Address of your network drive.   |
| <b>Firmware Version</b>     | The current firmware version.  |
| <b>Kernel Version</b>       | The current kernel version of the system.  |
| <b>System Time</b>          | The date and time of the system.   |

From: <http://wiki.myakitio.com/> - MyAkitio Wiki

Permanent link: [http://wiki.myakitio.com/system\\_information\\_server\\_info](http://wiki.myakitio.com/system_information_server_info)

Last update: 2012/09/04 11:25

